

MACBOX #2000

MACBOX #2000

- 100% Chemical free
- Strong
- Durable
- Easy assembly
- Custom sizing on request



100% Organic



06 376 7676

lumberprocessors.co.nz

enquiries@lumberprocessors.co.nz

**LUMBER
PROCESSORS**

Superior Timber, Honest Service,
Successful Investment...

MacBox Kitset Garden Box Assembly Guide

Tools Needed: Drill, Level

1. Prepare Your Workspace:

- Choose a flat and level area for the assembly of your garden box.

2. Lay Out Components:

- Lay out all the components on a clean and flat surface.

3. Build the Frame:

- Stand up one post and effortlessly insert the boards into the designated slots on the post.
- Continue this process, inserting boards into each side of the post until all boards are snugly in place.

4. Secure with Bugle Screws:

- Utilize the provided bugle screws to firmly fasten the boards to the posts. (#See diagram)
- Before securing with a screw, double-check that each board is fully inserted into the post.
- Use one screw per board for a secure fit.

5. Final Checks:

- Ensure all screws and fasteners are tightened securely.
- Confirm the stability and levelness of your garden box.

6. Completion:

- Congratulations! You have successfully assembled your MacBox kitset garden box.
- Get ready for happy gardening in your new space!

